

www.medallionrefinish.com

5751 N. Webster Street Dayton, OH 45414-0802 Toll-Free 937-890-6547 Phone 800-257-6547 Fax 937-890-6320

RS-722

TECHNICAL DATA

Rigid Parts Adhesive

DESCRIPTION:

RS-722 is specifically formulated as a structural adhesive for permanently attaching plastic autobody parts such as SMC, FRP and polyurea to metal, aluminum and plastic.



APPLICATION:

- 1. Clean all surfaces to be bonded with RS-620 Flexi-Clean to remove any wax, grease and dirt.
- 2. Scuff all surfaces to be bonded with 80 grit paper.
- 3. Wipe scuffed areas with clean, dry cloth to remove sanding dust. Clean areas with RS-620 Flexi-Clean to remove any excess dirt.
- 4. Mix together two equal lengths of RS-722 Rigid Parts Adhesive, Part A and Part B; 1:1 ratio. Mix to a consistent color.
- 5. Apply RS-722 Rigid Parts Adhesive to all surfaces to be bonded. Position reinforcing strip to backside of repair. Assemble within 15 minutes of mixing. Clamp if necessary.
- 6. Allow RS-722 Rigid Parts Adhesive to cure for 30 minutes. When cured, finish exterior panel with RS-720 Rigid Parts Filler

